



1600

 **TENSIO**



30 - 40 min

S1 **4\*12**



x2

S2 **8\*25**



x8

S3 **8\*16**



x15

S4 **5\*16**



x2

S5 **4\*14**



x36

S6 **6mm**



x1

S7 **3mm**



x1

S8



x3

S9



x4

S10



x2

S11



x2

G



x1

H



x2

I




x2

J



x2

A



x2

B



x1

C



x1

D



x1

E




x1

F



x1

K



x1

M






x1

N




x1


# 1



# 2




# 3




**MAKE SURE THE FRONT LABELS ARE IN THE SAME DIRECTION.**

# 4




**STEP 1**




**STEP 2**

# 5




**STEP 1**




**STEP 2**

# 6




# 7




**PLEASE MAKE SURE THE TABLE LEGS ARE VERTICAL TO THE CONNECTING ROD.  
AND THEN TIGHTEN ALL THE SCREWS.**

# 8




# 9



# 10


1600  
**TENSIO**



**RESET**

AFTER THE TABLE IS INSTALLED  
PLEASE PRESS THE  KEY TO START.

THE TABLE WILL BE AUTOMATICALLY DROP TO THE LOWEST POINT, STAY FOR 3 SECONDS, THEN RISE TO THE HIGHEST POINT, AND FINALLY RETURN TO THE INITIAL POSITION - SUCCESSFUL INSTALLATION.



# DIABLO

CHAIRS



Perseus è  
disponibile  
in versione



800.74.63.63